



NOTES:

1. PLACE HORSESHOE MANHOLE BASE IN WET CONCRETE (2,500 PSI).
2. CUT OUT TOP THIRD OF EXISTING PIPE. FINISH INVERTS AND WATERPROOF ALL COLD JOINTS AND AROUND ALL PIPES.
3. POUR CONCRETE COLLARS.

NOT TO SCALE