



IN-LINE BLOW-OFF



DEAD END BLOW-OFF



NOTES:

1. INSTALL 2" BLOW-OFF ON 2" THRU 8" MAINS.
2. INSTALL 2.5" BLOW-OFF ON 12" MAINS.
3. 2" & 2.5" BLOW-OFFS TO HAVE (NPT) COUPLING
4. INSTALL 4" BLOW-OFF ON 16" MAINS.
5. INSTALL 6" BLOW-OFF ON 24" MAINS.
6. IF THE SEPARATION BETWEEN THE CONTROL VALVE AND THE BLOW-OFF DOES NOT ALLOW THE INSTALLATION OF THE CONCRETE PROTECTOR RINGS, A 24" BY 24" BY 6" THICK CONCRETE PAD SHALL BE FORMED AND POURED AROUND THE VALVE BOX. THE EDGE OF THE VALVE BOX RIM MUST BE AT LEAST 8" FROM THE EDGE OF THE CONCRETE PAD.

NOT TO SCALE